VINYL WALLCOVERING - INSTALLATION INSTRUCTIONS

Wall surface must be clean, smooth, dry and properly prepared before installation.

Prepare Wall Surface:

- Strip existing wall coverings before installing new ones.
- Sand glossy paint using 80-grit sandpaper for maximum adhesion. Flat paint does not need to be sanded.
- Fill holes or blemishes with drywall joint compound using a putty knife. Allow it to dry, then sand smooth with 220-grit sandpaper.
- Wipe the wall with a tack cloth to remove sanding dust.

Note: Site and wall conditions may vary. Contact a company representative for guidance to avoid installation errors.

Install Vinyl Wallcoverings:

- Apply acrylic or latex wall-covering primer using a brush or roller. Allow the primer to dry completely.
- Apply BARTOLINE Heavy Duty vinyl wall-covering adhesive to the back of the sheet using a wallpaper brush or short-napped roller.
- Position and press the wallcovering onto the wall. Trim along the bottom edge as required using a utility knife and metal ruler. Follow company instructions for designs and patterns.
- Brush from the centre outward with a wallpaper brush to remove air pockets and smooth the surface.
- Repeat to cover the wall or room. Roll seams with a seam roller to secure adhesion and remove air bubbles.
- Wipe excess adhesive immediately using a sponge or rag.
- Recommended adhesive: BARTOLINE Heavy Duty.

Things Needed:

80-grit sandpaper; drywall joint compound; putty knife; 220-grit sandpaper; tack cloth; acrylic or latex primer; roller or wallpaper brush; vinyl wall-covering adhesive; utility knife; metal ruler; seam roller; rags or sponges.

Warning: Avoid oil-based primers when using vinyl wallcovering.

Tip: Consult the product manufacturer to confirm adhesive suitability. Adhesive selection is typically based on the wallcovering weight.

NOTE: Vinyl wallcovering must be installed by a professional and trained vinyl wallcovering installer.