

VIBRANT LVT CLICK N LOC – INSTALLATION INSTRUCTIONS

Floor must be dry, levelled & crack free.

- **Plan the Layout:** Determine the direction you want to install the planks/tiles (usually parallel to the longest wall or the main light source).
- **Begin Laying Planks/Tiles:**
 - Start in one corner of the room.
 - Place the first Plank/tile in the corner with the tongue side facing the wall.
 - Use spacers to maintain a gap (typically 1/4 inch) between the plank/tile and the wall for expansion.
- **Click the Tiles/Planks Together:**
 - Align the next plank/tile at an angle with the first plank/tile, ensuring the tongue and groove fit together.
 - Press down to lock the plank/tiles in place. You may need to tap the edge gently with a rubber mallet if needed.
- **Continue the Rows:** Repeat the process, working row by row. Stagger the joints between rows for a more natural look.
- **Cut Planks/Tiles as Needed:** Use a utility knife and straightedge to cut tiles at the edges or around obstacles.
- **Final Row Installation:** For the last row, you may need to cut the tiles to fit snugly against the wall. Leave a gap with spacers.
- **Remove Spacers:** Once all planks/tiles are laid, remove spacers carefully.
- **Install Transition Strips:** If necessary, add transition strips at doorways or where the flooring meets other types.

NOTE: The flooring must be installed by professional installer.